


CAR ALARM SYSTEM

MASTER

HUGE



INSTALLATION MANUAL



CAR ALARM SYSTEM

MASTER

HUGE



INSTALLATION MANUAL

Installation

Installation of the central unit.


Always instal the central inside the car`s compartment-at difficult of access and safety place. The level of temperature, vibrations and wetness must be minimum there.

Comfortable places for mounting are: under the panel,behind the drawer and other panels.

Cable connection

All system cables must be connected reliably to the corresponding cables of the car, by coupling or by welding them.The cables have to be isolated with qualitative adhesive tape or shrinkable folio.

Take care to the connections to "ground".



Installation

Instalation of the central unit.

Always instal the central inside the car`s compartment-at difficult of access and safety place. The level of temperature, vibrations and wetness must be minimum there.

Comfortable places for mounting are: under the panel,behind the drawer and other panels.

Cable connection

All system cables must be connected reliably to the corresponding cables of the car, by coupling or by welding them.The cables have to be isolated with qualitative adhesive tape or shrinkable folio.

Take care to the connections to "ground".

